




Montering av antennekontakt




Termiering av
inngående kabel.



EKO0NB118-03
08/25
NB118
Rev. 3

Bruksanvisning for Antennekontakt

RS16/Antenne	1 dB
RS16/Antenne	7 dB
RS16/Antenne	14 dB
RS16/Antenne m/satelitt	



Schneider Electric Industries SAS
35 rue Joseph Monier
FR-92500 Rueil Malmaison
elko.no/contact



